

IR



LED-BULB

Led-bulb remote indicator for battery charger of the S-T series on-board mounted: battery level indicator.

CODE	
IR	

PR20



PR20 CONSOLLE

With PR20 console is possible to read electrical parameters during charge, change pre-set parameters such as charging current, battery type, post-charge voltage, post-charge time.

CODE	
PR20	